

Art.Nr.310 1000 / S

[illegible]

This exploded view diagram illustrates the components of the AEG 1000 W hand dryer. The central component is the main hand dryer unit, which features a curved nozzle and a control knob. To the left, a power cord with a standard two-prong electrical plug is shown. Below the power cord is a rectangular control switch with a sliding lever. To the right of the main unit, several mounting and adjustment parts are shown, including two C-shaped brackets, two screws, a long vertical rod, and a circular base plate. A long, thin rod with a hook at one end is also shown on the far right. The diagram is a technical line drawing with no shading or color.