




TECEfloor Komfort Heizkreisverteiler Typ Logo
Nur mit Systemrohr und Systemwerkzeug zu verwenden.

Achtung: nicht geeignet für Standard-Rohrtypen!

TECEfloor comfort heating circuit manifold typ Logo

Only in use with system pipe and system tools.

Attention: unsuitable for standard pipes!

TECEfloor Colector para circuitos de calefacción Comfort tipo Logo

Sólo utilizar con tubería y herramienta del sistema.

Atención: ¡no apto para tuberías estándar!

TECEfloor: Коллектор контура комфортного отопления тип Logo

Только для использования с трубами и инструментом системы.

Внимание: не подходит для стандартных труб!

TECEtherm Collecteur de circuits de chauffage confortinox type Logo

A n'utiliser qu'avec le tube et les outils du système.

Attention: Ne convient pas à d'autre type de tube!

TECEradiator: Collettori circuito di riscaldamento comfort per Logo

Da utilizzare solo con tubi e attrezzi del sistema.

Attenzione: non utilizzare con altre tubazioni!


TECEfloor rozdzielacz komfortowego obiegu grzewczego typu Logo

Do wykorzystania tylko z systemowymi rurami i narzędziami.


Uwaga! Nie nadaje się do rur standardowych!

Technische Daten/Technical data

T_{max}/p_{max}	90 °C / 3 bar 80 °C / 4 bar 70 °C / 5 bar 60 °C / 6 bar
Verteilerdurchfluß/Water quantity per distributor	max. 3,5 m³/h
Kvs Vor- + Rücklauf-Ventil/Kvs flow + return valve	1,05 m³/h



Kreise/ Circuits	2	3	4	5	6	7	8	9	10	11	12
a	202	252	302	352	402	452	502	552	602	652	702
b	100	150	200	250	300	350	400	450	500	550	600



TECEfloor Soft PE-RT 5S 16 x 2 mm
7711 16 xx

TECEfloor SLQ PE-RT/Al/PE-RT 16 x 2 mm
7715 16 xx

TECEfloor SLQ PE-Xa 16 x 2 mm
7717 16 xx

TECElogo PE-RT / PE-Xc MLC 16 x 2 mm
870 xx 16

DIM 16 x 2

TECElogo 876 00 xx
TECEfloor 7792 00 4x

