




CERAPLAN

Ideal Standard



Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever, w/logo	B961716AA	1 Set	13a	Noice reducer	A963777AT**	1 Set
2	Cap decorative	B960473AA	1 Pcs.	14	Hose flexible G1/2 /L1800	A963173NU	1 Pcs.
3	Rosette M38x1.5	B961438AA	1 Pcs.	15	Wall fix	B1364AA	1 Pcs.
4	Screw M41x1.5/M38x1.5	B961374NU	1 Set	16	Wall bracket	B960925AA	1 Pcs.
5	Hot limit stop	A861181NU	1 Pcs.				
6	Cartridge Ø38mm	A861156NU*	1 Pcs.				
7	O-Ring Ø38x2.5	E960059NU*	1 Set				
8	Pull knob	B960486AA	1 Pcs.				
9	Nozzle	A961625AA	1 Pcs.				
	Neop.cascade M24x1-D	A960537AA**	1 Pcs.				
10	Diverter automatic	B960167AA	1 Pcs.				
11	Rv-patrone	A960944NU	2 Pcs.				
12	Connecting set	A964520NU	1 Set				
13	Connector G3/8, Ø15-set	B960845NU	1 Set				

\*\* (for BD257AA)

\*Universal set (not all parts needed)

05.2021