





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
/ Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu


Pos.	Part No.
1	A 860 896 AA
2	A 960 893 AA
3	A 960 500 NU
4	F 960 880 AA
5	F 960 876 AA
6	A 860 691 NU
7	A 960 071 NU
8	A 961 863 NU
9	A 861 270 NU
10	A 963 526 NU
11	A 861 000 NU
12	F 960 881 NU
13	A 963 548 NU
14	F 960 866 NU



Ideal Standard





Tonic II
A 6334 .. A 6335 ..

0325 / A 868 814
Made in Germany



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<https://www.idealstandard.com>





	P	bar		MAX. 10		5		Q (3 bar)
	T	°C		MAX. 80		65		
						55		l/min
								5

