



Ordering spares / Ersatzteil - Regelung / Pièces de rechange /  
Parti di ricambio / Lista de recambios / Onderdelen bestellen  
(NL/B) / Κωδικό Ανταλλακτικών / Bestilling af reservedele  
/ Beställning av reservdelar / Bestilling av reservedeler /  
Резервни части / Запчасти / Części zapasowe / Piese de  
schimb / Rendelhető alkatrészek / Запасні частини / Резервни  
делови / Резервни делови / Atsarginių dalių / Tellitavad varu-  
osad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek  
parça siparişi / Nadomestni deli


XX = AA, AD, .....

1 - A 861244 NU - RH

A 861243 NU - LH






# JOY NEO



## Ideal Standard

12.2021 / B565171

B D355 ..



Ideal Standard International NV  
Corporate Village – Gent Building  
Da Vincilaan 2  
1935 Zaventem  
Belgium

<http://www.idealstandardinternational.com>

