
















DE Gebrauchsanleitung / Montageanleitung
GB Instructions for use / Assembly instructions
BG Brúgsanvísing / Monteringsvejledning
DK Mode d'emploi / Instruccions de montage
FR Gebruiksaanwijzing / Handleiding
NL Bruksanvisning / Montasjeveleiding
NO Instruccja obsługi / Instrukcja montażu
PL Instruções para uso / Manual de instalação
PT Návod k použití / Montážní návod
CZ Használati útmutató / Szerelési útmutató
HU Bruksanvisning / Monteringsanvisning
SV Modo de empleo / Instrucciones de montaje
ES Руководство пользователя /
RU Инструкция по монтажу
IT Istruzioni per l'installazione / Istruzioni per l'uso
SK Montážny návod / Návod na použítie



 Schlösser Armaturen GmbH & Co. KG
Im Dohm 3
57462 Olpe
GERMANY
 www.schloesser-armaturen.de
 info@schloesser-armaturen.de



00157732000001

01 00181832000001
02 00185908000001
03 00183608000001
04 00183108000001
05 00186032000001

